

# BE CHAIR OPERATING MANUAL



**1 FLEX BACK:** Sit back and the Flex Back supports you and responds to your body movement.

**2 FLEX TOP:** Rest over the Flex Back comfortably with the Flex Top.

**3 FLEX SEAT:** Supports you in any position with its 270 degree seat edge flex.

**4 DYNAMIC SUSPENSION CONTROL:** The synchronized recline counterbalances your body weight for a smooth and effortless ride. Four independent flexors act as suspension devices that respond to your multidirectional movements- forward, backward and side to side.

**5 SEAT HEIGHT:** Lift the lever situated on the front right side, sit down to lower the height or remove your weight to raise the height. Release lever to lock into position.

**6 SEAT DEPTH:** While seated, lift the lever on the left side and slide your seat to the desired position. Release the lever to lock into position.

**7 TILT PREFERENCE SELECTOR:** Sit upright and rotate the back right lever until it clicks into one of three positions- back for the most movement, middle for less and forward for greater upright support.

**8 HIGH PERFORMANCE ARM:** To adjust the height, lift the lever on the arm and lift the arm to disengage. Slide the arm to the desired position and release the lever to lock.

**9 HEIGHT ADJUSTABLE LUMBAR:** Grasp both sides of the lumbar support and slide it to the desired position.

